

感谢您购买 奥兰多汉特 攀爬系列 ORLANDO HUNTER 模型。

请您务必仔细阅读说明书，根据说明书的提示来帮助您完成您的模型。本套件为KIT散件版本，需要您动手组装上色及调试。

Thanks for choosing **ORLANDO HUNTER** ROCK CRAWLER Series **ORLANDO HUNTER** model. Please read our instructions carefully, and following our instructions to help you finish assembling the model. The kits are parts, need assembling, painting and debugging by yourself.

本套件不含电子设备，您至少还需购买：

The kits are not including the following parts which you need to buy:



发射机 Transmitter    接收器 Receiver    调速器 Mini ESC    减速电机 Motor    2.2g 舵机 2.2g Servo    锂电池 Li-po    充电器 Charger

您还需要购买涂料、遮盖胶带、流缝胶、美工刀等工具辅料，来协助您完成您的模型。

Besides, in order to finish your model, following Supplementary material you also need to buy: Coating, Masking Tape, Seam Glue, Utility Knife.



涂料 Coating    遮盖胶 Masking Tape    流缝胶 Seam Glue    美工刀 Utility Knife

您还可以升级灯光设备，选择微型灯光控制器、LED灯珠及贴片，使模型更仿真。还可选择轮毂配重环，降低整车重心，提高姿态仿真。

Besides, in order to upgrade your model, following light material you also need to buy: Mini Lamp control, 4mm LED bulb, smd LED, balance weight.



微型灯控 Lamp Control    LED灯珠 4mm LED    贴片LED SMD LED    配重环 Balance Weight

## 警告 WARNING

**本套件不适合14岁以下使用！**


The kits are not suitable for child under 14 years old!



套件内含大量微小零件，若儿童吸入或误食，可能会导致窒息等危险！请务必放置于儿童不易接触的地方！

The kits including many mini parts, if the child inhalation or mistake eaten, can cause choking or other serious hazard! Please be sure put the model at the place where child can not touch it!

SIZE 135th *ORLANDO HUNTER*



## 尺寸/参数 SIZE / DATA

长度 L	宽度 W	高度 H	轴距 T	轴距 W.H
170mm	70mm	63mm	58mm	106mm

## 注意 ATTENTION

组装完成后的模型内含有高减速比齿轮及微型传动系统，请不要尝试使用一切外力强制推动汽车模型。这将可能损坏传动系统及齿轮组件！

模型内含有微型连接件及外观仿真件，请防止高空坠落或挤压模型。这将可能损坏微型部件及外观零件！

请勿将模型长时间放置于阳光下，这将可能加速塑料及橡胶的老化！

After finish assembling the model, please do not use any large strength to push the model, since the inside have high reduction ratio gearwheel and mini transmission system, if do will cause the transmission system be damaged!

Since the model have the mini connection parts and simulation parts inside, please avoid the model be altitude fall or squeezed, otherwise, it will cause the damage of mini connection parts and simulation parts!

Please do not put the model in the sun at long time, otherwise, it will accelerate aging of the plastic and rubber parts!

## 警告 WARNING

套件内用于包装的塑料袋使用后请及时收好，或者丢弃在可回收垃圾桶内。请勿让儿童当做玩具，可能会导致窒息危险！

The plastic bag of kits, after using please promptly put away or throws into the recyclable rubbish bin, if get by child, might have choking hazard!

## 提示 TIPS

在开始组装前，请先准备好所需要用到的工具，按照说明书左侧提示打开相对应的包裹（不要将所有零件包全部打开或全部取出，以免弄混或者丢失），取出相对应的零件（只需要取出左侧标注的零件数量）。因个别零件尺寸比较小，特别是螺丝等小零件，非常容易丢失，使用小盘子、小盒子等来放置待组装的小零件，能有效防止其丢失。

取出零件后如发现毛刺或飞边的，请先用美工刀进行修整，再用砂纸打磨光洁后再进行组装。进行这一步骤后将对组装完成后运行的流畅性和美观性有进一步提升。

组装小零件时注意控制力度，以免损坏零件或使零件掉落而丢失。

Before assembling, please according the instructions tips to open and take out corresponding package, ready for all the tool you need (please not open all the package, it will cause the parts lost or confused). Because some spare parts are really very small, especially the screw etc., which is easily missing, you can put them into a small dish or box first to avoid missing.

Before assembling check the spare parts first, if any burr found, please use utility knife to make it flat, and then use sandpaper to make it smooth. After doing this the fluency and aesthetics of the model will be upgraded.


During assembling the spare parts, please do not use over strength or else will cause the spare parts break or drop.

## 部件/编号对照 PARTS / REFERENCE NUMBER

以下为 奥兰多汉特 攀爬系列 **OH35 Per KIT** 所包含的所有零部件编号及数量对照表。  
如组装或者使用过程中损坏或者丢失其中一些部件，可按照零部件编号购买相应的零部件用以替换。  
如需要对模型进行改装及加装，也可按照所需要改装或加装的零部件的编号进行购买。


Following is the comparison table of all spare parts and numbers of the **ORLANDOO - HUNTER** ROCK CRAWLER Series **OH35 Per KIT** Model.

During the assembling, if some spare parts break or lost, you can according the number in the chart to buy a new one to replace it. If need remodel or adding, also can according the chart to buy some additional spare parts.





**1X**

OHPC35201 **4**




**1X**

OHPC35201 **3**




**1X**

OHPC35201 **1**



**1X**

OHPC35001 **2**





**1X**

OHPC35001 **3**

**1X**

OHPC35201 **5**





**1X**  
 OHPC35001 **4**




**2X**  
 OHPC35001 **5**




**1X**  
 OHPC35001 **6**



**1X**  
 OHPC35001 **7**




**1X**  
 OHPC35201 **2**



**2X** OHPCA20124




**1X**  
 OHPC35101 **2**




**1X**  
 OHPC35101 **3**




**1X**  
 OHPC35101 **4**


















**1X**  
 OHPC35101 **1**



**1X**  
 OHPCB30095



**1X**  
 OHPC52001



OH35 Pin KIT



**26X**  
 OHMLA20162

**1X**  
 OHMLA2016B

**4X**  
 OHSW90102

**10X**  
 OHSW01003

**1X**  
 OHSW82002

**4X**  
 OHSW01005

**12X**  
 OHSW01205


**2X**  
 OHSW01503

**11X**  
 OHSW31605


**6X**  
 OHSW01505



**1X**  
 OHTLB32001



**1X**  
 OHTLB10020



**1X**  
 OHTLB20001



**1X**  
 OHTLZ00014



**1X**  
 OHTLB40009

### 工具包内包含 TOOL CONTENTS

十字螺丝刀	Phillips Screwdriver
六角锁胎器	Nut Driver
钻头夹持器	Tool Handle
1.4mm钻头	Drill 1.4mm
内六角扳手	"L" Type Hexagon Screwdriver
双面减震垫	Double Side Tape

以下图标将会出现在接下来的装配图中，请先了解图标的含义！  
 Following icon will appear on the assembling chart, please understanding its meaning first!



需要润滑  
 Requiring  
 Lubrication



制作两份  
 Make  
 Two Copies



制作四份  
 Make  
 Four Copies



开孔  
 Drill hole



需上色  
 Requiring Color



流缝胶  
 Requiring  
 Glue




选择  
 Requiring  
 Select




注意  
 Attention

**A**  
打开包裹“A”


**1**



2X OHPCF30561



2X OHPCF30562



2X OHMCB06250



2X OHMCB06130




4X OHBG50825



2X OHBG30625



4X OHSW01205




OHPCF30562

**2x**



OHBG50825




OHMCB06250




OHBG50825




OHMCB06130



OHBG30625




OHPCF30561



轴承嵌入后保持平整及到位！  
After bearing embedded remain flat and in place!






2X OHPCF30563




2X OHMLC30001



2X OHBG30625



4X OHMLA20162



4X OHSW01003

**2**

轴承嵌入后保持平整及到位！  
 After bearing embedded remain flat and in place!

OHMLC30001  
 OHSW01003  
 OHMLA20162  
 OHMLA20162  
 OHBG30625  
 OHPCF30563  
 OHSW01003  
 OHSW01003  
 OHSW01003  
 OHSW01003  
 OHMLC30001



2X OHPCF30564



2X OHMLC30002



2X OHBG30625



1X OHMLA2016B



1X OHMLA20162

**3**


轴承嵌入后保持平整及到位！  
 After bearing embedded remain flat and in place!

OHMLC30002  
 OHMLC30002  
 OHBG30625  
 OHMLA2016B  
 OHMLA20162  
 OHMLA20162  
 OHPCF30564  
 OHMLA20162

注意零件方向！  
 Pay attention the direction of the spare parts!

注意零件方向！  
 Pay attention the direction of the spare parts!

注意零件方向！  
 Pay attention the direction of the spare parts!



1X OHPCF30567



1X OHPCF30566




2X OHMLA20162



1X OHSW01003



2X OHSW01205




1X OHMLA20162




1X OHSW01003




2X OHSW01505





1X OHPCF30568



2X OHMLC30003



2X OHMLA20162




2X OHSW01205

6

OHMLA20162



OHPCF30568




OHMLA20162



钻孔时请垂直于需钻孔的平面！  
 注意两端对称！

Drilling is a plane perpendicular to the drill hole!  
 Notice the symmetry of both ends!




1

OHMLC30003

OHMLC30003



注意零件方向!  
 Pay attention the direction  
 of the spare parts!



2X OHPCF30565



2X OHBG30625




4X OHMLA20162



4X OHSW01003

7



轴承嵌入后保持平整及到位!  
 After bearing embedded remain  
 flat and in place!


OHBG30625

2X

OHPCF30565

OHMLA20162

OHMLA20162



6



注意零件方向!  
 Pay attention the direction  
 of the spare parts!



注意零件方向!  
 Pay attention the direction  
 of the spare parts!

**B**

打开包裹“B”


**1X** OHMLB01218**8**

OHPCA20124



OHMLB01218

OHPCA20124



装配后请测量平面至平面距离约为11mm，两端拉杆头需成90度角。

After assembling, please measure the distance between planes should be about 11mm, both two rod ends should be 90 degree.

**9****4X** OHMLB01225


OHPCA20124



OHMLB01225

**4X**

OHPCA20124



装配后请测量平面至平面距离约为18mm，两端拉杆头保持平行。

After assembling, please measure the distance between planes should be about 18mm. Both two rod ends should keep parallel.


**10****1X** OHMLB01235

OHPCA20124



OHMLB01235

29mm




装配后请测量平面至平面距离约为29mm，两端拉杆头保持平行。

After assembling, please measure the distance between planes should be about 29mm. Both two rod ends should keep parallel.

OHPCA20124

**11****4X** OHMLB01240


OHPCA20124



OHMLB01240

**4X**

33mm




装配后请测量平面至平面距离约为33mm，两端拉杆头保持平行。

After assembling, please measure the distance between planes should be about 33mm. Both two rod ends should keep parallel.


OHPCA20124

**81416**  
OH35 Pin KIT

**12**




**13**




**C**



打开包裹“C”



1X OHPC35201 1


 12X OHMLA20162
**14**

钻孔时请垂直于需钻孔的平面！  
注意两端对称！  
Drilling is a plane perpendicular to the drill hole!  
Notice the symmetry of both ends!



 OH35 Pen Kit



**15**




**4X** OHBG30625



**1X** OHMCA05191




**1X** OHMCA05192




**1X** OHMCA05193



**1X** OHSW82002



**1X** OHPC35201 **2**




**1X** OHPC35201 **3**



**3X** OHSW31605




**4X** OHSW01505



OHPC35201 **3**



可插入4mm LED灯珠。  
Embed in 4mm LED lamp beads.



可插入贴片LED。  
Embed in SMD LED.



本套件内不包含LED灯组！  
The kits do not included any LED lamp.



OHMCA05191



OHBG30625


OHMCA05192

OHBG30625

OHSW01505

OHSW01505


OHSW1505



OHMCA05193

OHBG30625

OHSW31605



本套件内不包含电机！  
 减速电机减速组尺寸为12mm\*10mm\*9mm，  
 电机最长限制为18mm，  
 减速组输出轴径为3mm 轴长4.5mm。  
 The kits not included any motor!  
 The decelerate size is 12mm\*10mm\*9mm,  
 The max length of motor is 18mm,  
 The deceleration group output shaft diameter is 3mm,  
 shaft length is 4.5mm.

# D


打开包裹'D'

4X OHMLD01010

4X OHSGA03001

4X OHSW01005


16



请调整减震距离约为14mm。  
Please adjust the distance between shock absorber.  
请使用尖嘴钳夹住丝杆再拧入减震座。  
Please use Needle-nose pliers clamp to rod then twist into the shock absorber seat.




螺丝请勿拧入过紧，过紧可能导致减震筒身变形，导致顺滑度降低！  
Do not twist the screw too tight, if too tight will cause the deformation of the shock absorber tube!



选择安装减震软硬调节垫片。  
Gaskets in the installation of appropriate selective.



17



套入万向节时请控制力度，零件较小，请耐心组装。  
Do not use over strength to set the universal ball, due to the small spare parts, please be patient when assembling.


**4X** OHSW01205

**18**




**E**  
打开包裹'E'


19



1X OHPC35201 5



1X OHPC35201 3




1X OHPC35101 3



1X OHPC35101 4




6X OHSW31605



1X OHPC35202 2



本套件内不包含LED灯组！  
The kits do not included any LED lamp.



可插入贴片LED。  
Embed in SMD LED.




黑色  
Black



自定义颜色  
Custom Colors




透明红  
Clear Red



18



20




在车壳喷漆前，检查表面若发现有瑕疵，请用砂纸打磨后，再使用补土修补凹痕，然后进行细打磨。喷漆时注意每次喷薄一点，多喷几次，质感更好。喷保护漆后表面再用研磨膏打磨，效果更佳。喷漆时请戴好口罩、护目镜在室外通风处进行！

Before painting the car shell, check whether the shell surface have any defect, once found defect, please use the sandpaper make the surface smooth, then use fill soil to cover the dent.  
 When spray the shell please each time spray little, try to spray more times, it will show better Textured.  
 After spray the shell, then use the polishing paste to polishing, will get better effective.  
 When spray the shell, please wear masks and goggle first and work at the outdoor ventilation place!


1X OHSW31605

21




1X OHPC35201 4

20




19

OHPC35201 4



OHSW31605

OHSW31605




**8Ballz**  
OH35Per KIT

**F**  
打开包裹“F”


4X OHSW90102



4X OHPCG30815 **1**



4X OHTE27101




4X OHSE02814

**22**

**21**


OHSW90102



OHPCG30815 **1**



**4X**




OHTE27101

OHSE02814

OHSW90102




OHSW90102



**21**

OHSW90102





## 车桥/轴距调整 AXLE / WHEELBASE ADJUSTMENT


组装完毕后，如未发现车桥有明显扭曲或偏向一侧，请跳过这一步骤！

如发现车桥有严重扭曲或偏向一侧，请先拆除下拉杆，按照以下图示进行调整！

调整方法：取下拉杆，顺时针拧动拉杆头为缩短拉杆长度，反之增加拉杆长度！

After assembling, if you not found any deformation or offset to one side of axle, please skip this step! If you found any deformation or offset to one side of axle, please dismantle the rod first, then according the chart to adjust!!

Adjustment method: take out the rod, and twist the head of rod in clockwise direction to make the rod shorter, on the contrary will make the rod longer!




首先拆除下拉杆后将车桥摆正  
(车桥轴线和车身纵线垂直)

检查车桥是否向一侧偏移

如向左侧偏移，请缩短右侧上拉杆或增加左侧上拉杆的长度！反之逆向调整！

调平后将下拉杆装回。



拉杆调整较繁琐，请耐心调整！  
Rod adjustment is complicated,  
please be more patient!


Dismantle the rod, then straightened the axle.  
(axis of Axle should be perpendicular to the body longitudinal line)  
Check whether axle is offset to one side, if offset to the left, please shorten the rod on the right or increase the length of the lever on the left side!

Or adjustment on the contrary! After it on the level! Then fix back the under rod.

After assembling the lower rod, check whether the axle offset to one side or not!

As offset to the left, please shorten the length of lower rod on the right side, or increasing the length of the left side of the rod!

Or adjustment on the contrary! Then complete above to next step.



车桥扭曲偏移调平后将模型放置于平面，检查车轮是否有前后位置及车桥角度偏差。如有偏差请按以下说明调整。

前后桥输出轴和平面的倾斜角度约为5度，角度过大或过小可能会增加轴效应，导致模型运行不流畅。

如角度过大，请缩短上拉杆的长度或增加下拉杆的长度；如角度过小，请增加上拉杆的长度或缩短下拉杆的长度。

如前桥太靠前，请同时缩短上下拉杆的长度；太靠后，请同时增加上下拉杆的长度。  
后桥调整方式同前桥。

The inclination angle of the front and rear axle between the output shaft and the plane was about 5 degrees, angle is too large or too small may increase shaft effect, and will also cause the model to run not smooth.

If the angle is too large, shorten the length of the upper rod or increase the length of the lower rod; if the angle is too small, increase the length of the upper rod or shorten the length of lower rod.

If the front axle is too close front, please also shorten the length of the upper and lower rod at the same time; if too close the rear side, please also increase the length of the upper and lower rod at the same time. Please note that rear axle adjustment method as same as the front axle adjustment method.

## 配重/重心调整 COUNTERWEIGHT / WEIGHT ADJUSTMENT

模型加入设备后重心位置会发生改变，可在底盘上增加配重来达到前后左右的平衡，底盘以上配重不宜过重，配重物放置位置越低，则车辆稳定性越好。

您还可购买轮毂配重环增加4个轮胎的重量，或使用软铅丝或焊锡丝在轮毂和胎皮之间均匀缠绕达到配重效果，注意左右两侧轮胎配重要一致，前轮可适当增加配重。轮毂配重后，整车重心进一步降低，行进起伏路面时车辆扭曲更加仿真，爬陡坡时更能增加抓地力，重心降低后更不易翻车，性能更稳定！

Gravity position will be changed after the model was added equipment, you can add the balance weight the chassis to achieve equilibrium around. The over Chassis weight should not be too heavy, and the lower placement of balance weight, the vehicle stability will be better.

You can also buy the wheel hub balance weight to increase the weight of the four tires, or use a soft lead wire or solder between the hub and the tire cover wound achieve uniform weight effect.

Please note that the weight between left and right sides of the tire should be same, the front wheel can be appropriate to increase the weight, after the wheel hub the counterweight, the vehicle center of gravity will be lower. When the vehicle travelling the rough road, the twist much more like real vehicle, better grip while climbing a steep hillside, the center of gravity lower, more difficult to overturn and stable performance!